


amGard*pro* Configuration Tool



Step 1a: Choose the Actuator



Actuators

For use with 'M' Heads

For use with 'T' Heads

For use with 'I' or 'A' Heads

proAM Handle



Part No.	Description
MA	AM Handle


Turning motion holds door closed. Ideal for non locking set ups (i.e. proSTOP devices)



Part No.	Description
MI	AM Handle with Internal Release


Turning motion holds door closed. Internal handle allows user to open door from inside (pushIR may be required depending on application)

proAT Tongue



Part No.	Description
TA	AT Tongue

High strength and ease of opening makes this the most popular actuator in the amGardpro range.



Part No.	Description
TK	Short AT Tongue (allows padlocks through the tongue to work as a lock out tag out, but reduces over travel).

Allows padlocks through the tongue to work as a lock out tag out, but reduces over travel

proSlidebar Options



Part No.	Description
TN	Slidebar without a spring

Sliding motion holds door closed. With no return spring unit remains in the position it is left in



Part No.	Description
TS	Slidebar with a return spring

Sliding motion holds door closed. Return spring pulls the slidebar open, preventing clashes with the head (but requires the slidebar to be held forward whilst locking)



Part No.	Description
TI	Slidebar with Internal handle but no return spring

Sliding motion holds door closed. Same as a TN but IR knob allows door to be opened (but not closed) from the inside when main unit is unlocked



Part No.	Description
TM	Slidebar with Internal handle c/w TK Short Tongue

Sliding motion holds door closed. Short TK tongue allows padlock through tongue to act as a lock out. Additional lock out space at rear of slidebar



Part No.	Description
TG	Slidebar with Internal handle for GM

Sliding motion holds door closed. Short TK tongue allows padlock through tongue to act as a lock out. No additional lock out space at rear of slidebar



Part No.	Description
TF	Slidebar with Internal handle c/w spacer behind the knob

Same as a TN but IR knob allows door to be opened and closed from the inside when main unit is locked

proHandle Options



Part No.	Description
EN	proHandle, no Internal Release

Handle motion holds door closed, but no method to open door from inside



Part No.	Description
EF	proHandle, with Internal Access Handle

Handle motion holds door closed. Internal access handle allows door to be opened and closed from the inside



Part No.	Description
EH	proHandle (the red internal release handle only works with units with no locking (i.e. stops) or in conjunction with a Push IR unit).

The red internal release handle only works with units with no locking (i.e. Stops) or in conjunction with a pushIR unit

proRelease IR Handle



Part No.	Description
EI	proIR Handle to allow emergency release (only to be used with I6 or I7 head).

Handle motion holds door closed. Red handle overrides all locking mechanisms and opens safety contacts to allow escape release




MI, TI, TM, TG, TF and EH work well with a Push IR unit (see step 4)

Step 1b: Choose the Actuator

Actuators

For use with 'S' Heads

pro Slimline Tongue



Part No.	Description
*SA	Slimline Tongue

High strength, but suitable for all Slimline configurations

proSlidebar - Short Tongue Options



Part No.	Description
SN	Slimline Tongue Slidebar without a spring

Sliding motion holds door closed. With no return spring unit remains in the position it is left in



Part No.	Description
SS	Slimline Tongue Slidebar with a return spring

Sliding motion holds door closed. Return spring pulls the slidebar open, preventing clashes with the head (but requires the slidebar to be held forward whilst locking)



Part No.	Description
SI	Slimline Tongue Slidebar with Internal handle but no return spring

Sliding motion holds door closed. Same as a SN but IR knob allows door to be opened (but not closed) from the inside when main unit is unlocked



Part No.	Description
SF	Slimline Tongue Slidebar with Internal handle c/w spacer behind the knob

Same as a SN but IR knob allows door to be opened and closed from the inside when main unit is locked

pro Hand Operated Actuator



Part No.	Description
SD	Hand Operated Sprung Actuator with Slimline tongue

proHinged Handle Options



Part No.	Description
HS1	proHinged Handle - Short Reach for use with proStop units (40mm wide)

Particularly useful for applications using small radius hinged doors (250mm min)



Part No.	Description
HL1	proHinged Handle - Long Reach for use with proLok units (80mm wide)

Particularly useful for applications using small radius hinged doors (250mm min)

NO Actuator Required

X

Part No.	Description
NO	No Actuator required

Select this when you wish to specify head direction (Handing) but are not purchasing an actuator

pro
i
 "If you select an SA, SI, SN, SF, SS, SD, HS, HL you must then select Slimline Head S6 only"

pro
i
 "If no Actuator is required go to Step 3, where you can select a Head or Cap (C6)"

Step 2: Choose the Handing

Actuators



Part No.	Handing Description
1	Front Facing

Part No.	Handing Description
2	Left Hand

Part No.	Handing Description
3	Rear Facing

Part No.	Handing Description
4	Right Hand

pro i
Even if you have not chosen an actuator from Step 1 you can still choose handing for the head module

pro i
If you chosen an EI Actuator from Step 1, Front Facing, 1 and Rear Facing, 3 Handing options are not allowed



HS1S6ST401

pro i
If you choose a HS/HL Handle & an S6 Head it is recommended you choose a Front Facing configuration

Step 3: Choose the Head Module

Head Modules

proCap Options



Part No.	Description
C6	To terminate assemblies without heads

Terminates assemblies without heads

proAM Head Options



For use with actuators:
MA
MI

Part No.	Description
M6	proAM Head

Turning motion holds door closed. Ideal for non locking set ups (i.e. proSTOP devices)



For use with actuators:
MA
MI

Part No.	Description
M7	proAM Head c/w Drop Down Lockout

M6 head with drop down lockout. This lockout features slides into place every time actuator is removed. Ideal for applications where lockout is to be used on every entry



For use with actuators:
MA
MI

Part No.	Description
M8	proAM Head c/w Lock-Out Clip

M6 head with drop down clip. Ideal for applications where lockout is not to be used on every entry

proAT Head Options



For use with actuators:
TA TS
TK TM
TI TG
TN TF
EH EN

Part No.	Description
T6	proAT Head

High strength and ease of opening makes this the most popular head in the amGardpro range



For use with actuators:
TA TS
TK TM
TI TG
TN TF
EH EN

Part No.	Description
T7	proAT Head c/w Drop Down Lockout

T6 head with drop down lockout. This lockout features slides into place every time actuator is removed. Ideal for applications where lockout is to be used on every entry



For use with actuators:
TA TS
TK TM
TI TG
TN TF
EH EN

Part No.	Description
T8	proAT Head c/w ATL Lock-Out Clip

T6 head with drop down clip. Ideal for applications where lockout is not to be used on every entry

proAT Slimline Head Options



For use with actuators:
SA SF
SI SD
SS HS
SN HL

Part No.	Description
S6	proAT Slimline Head

S6 Head with the HL1 for the Lok must be forward facing only.

S6 Head with the HS1 for the Stop / Safety Key must be forward facing only.

S6 Head with the SA* Tongue for the Lok / Safety Key can be any facing.

pro i

An S6 head works especially well with a slimline proLok to give a final product that is only 40mm wide

proRelease IR Handle Options



For use with actuators:
EI

Part No.	Description
I6	proIR Head (only works in conjunction with EI handle)
A6	Auto reset all in one head (only works in conjunction with EI handle)

Handle motion holds door closed. Red handle overrides all locking mechanisms and opens safety contacts to allow escape release



For use with actuators:
EI

Part No.	Description
I7	proIR Head c/w drop down lockout (only works in conjunction with EI handle)
A7	Auto reset all in one head c/w drop down lockout (only works in conjunction with EI handle)

I6 / A6 head with drop down lockout. This lockout features slides into place every time actuator is removed. Ideal for applications where lockout is to be used on every entry

pro i
If a head module is not required, leave the part number blank and continue to Step 4

pro i
Ensure the head module you have selected works with the actuator you have selected in Step 1

Step 4: Do you want a Push IR

Adaptors

A Push IR will allow Internal Escape Release even if unit is locked by keys and or solenoid. A Push IR is **not** needed if an EI Handle and I6 / I7 or A6 / A7 Head have already been specified. (note, a pull reset (R6, R7, R8 & R9) reduces the safety of the system).



Part No.	Push IR Description
R1	Key Reset (up to 40mm panel thickness)

Same as RW but key reset to ensure all incidents are reported



Part No.	Push IR Description
R2	Key Reset (up to 60mm panel thickness)

Same as RX but key reset to ensure all incidents are reported




Part No.	Push IR Description
R3	Key Reset (up to 80mm panel thickness)

Same as RY but key reset to ensure all incidents are reported



Part No.	Push IR Description
R4	Key Reset (variable length - for panel thickness over 80mm and up to 1m)

Same as RZ but key reset to ensure all incidents are reported




Part No.	Push IR Description
R6	Pull Reset (up to 40mm panel thickness)

Same as RW but pull reset allows door to be relocked from the inside (requires careful risk assessment to ensure this is acceptable)



Part No.	Push IR Description
R7	Pull Reset (up to 60mm panel thickness)

Same as RX but pull reset allows door to be relocked from the inside (requires careful risk assessment to ensure this is acceptable)



Part No.	Push IR Description
R8	Pull Reset (up to 80mm panel thickness)

Same as RY but pull reset allows door to be relocked from the inside (requires careful risk assessment to ensure this is acceptable)



Part No.	Push IR Description
R9	Pull Reset (variable length for panel thickness over 80mm and up to 1m)

Same as RZ but pull reset allows door to be relocked from the inside (requires careful risk assessment to ensure this is acceptable)



Part No.	Push IR Description
RW	Front Reset no key (up to 40mm panel thickness)

Overrides all locking mechanisms and opens safety contacts to allow escape release. Simple push reset allows quick restart. Suitable for panels up to 40mm thick



Part No.	Push IR Description
RX	Front Reset no key (up to 60mm panel thickness)

Overrides all locking mechanisms and opens safety contacts to allow escape release. Simple push reset allows quick restart. Suitable for panels up to 60mm thick



Part No.	Push IR Description
RY	Front Reset no key (up to 80mm panel thickness)

Overrides all locking mechanisms and opens safety contacts to allow escape release. Simple push reset allows quick restart. Suitable for panels up to 80mm thick



Part No.	Push IR Description
RZ	Front Reset no key (variable length for panel thickness over 80mm up to 1m)

Overrides all locking mechanisms and open safety contacts to allow escape release. Simple push reset allows quick restart. Suitable for panels up to 300mm thick

pro
i

If a Push IR is not required leave part number blank and go to Step 5

Step 5: Choose an Extracted Key Adaptor

Adaptors




Part No.

E	K		
---	---	--	--

Description	Part No.
Standard Lock	L
Releasing Lock (must be used if a Push IR or EI Handle and Head used).	R

Description	Information		Part No.
Standard Lock no dustcover	Removed key ensures door cannot be locked until operator returns from cell with the key. Extracted version will not open door until key is removed	CLIN	1
Standard Lock with dustcover	Same as EK_1 but with dustcover for dusty environments	CLIS	2
Standard Lock with padlockable dustcover	Same as EK_1 but padlockable dustcover allows lockout feature	CLIL	3
Masterable Lock no dustcover	Same as EK_1 but master lock allows a single key to override all locks (master key must be carefully controlled on site)	MLIN	6
Masterable Lock with dustcover	Same as EK_2 but master lock allows a single key to override all locks (master key must be carefully controlled on site)	MLIS	7
Masterable Lock with padlockable dustcover	Same as EK_3 but master lock allows a single key to override all locks (master key must be carefully controlled on site)	MLIL	8



or

If you've selected an I6/I7 or A6/A7 then select a releasing lock.

If you've selected a Push IR adaptor then select a releasing lock.

pro
i

If an Extracted Key Adaptor is not required leave part number blank and go to Step 6

Step 6: Choose a Safety Key Adaptor

Adaptors




Part No.

S	K			
---	---	--	--	--

Description	Part No.
Standard Lock	L
Releasing Lock (must be used if a Push IR or EI Handle and Head used).	R

Description	Information		Part No.
Standard Lock no dustcover	Removed key ensures door cannot be locked until operator returns from cell with the key	CLIN	1
Standard Lock with dustcover	Same as SK_1 but with dustcover for dusty environments	CLIS	2
Standard Lock with padlockable dustcover	Same as SK_1 but padlockable dustcover allows lockout feature	CLIL	3
Masterable Lock no dustcover	Same as SK_1 but master lock allows a single key to override all locks (master key must be carefully controlled on site)	MLIN	6
Masterable Lock with dustcover	Same as SK_2 but master lock allows a single key to override all locks (master key must be carefully controlled on site)	MLIS	7
Masterable Lock with padlockable dustcover	Same as SK_3 but master lock allows a single key to override all locks (master key must be carefully controlled on site)	MLIL	8

Description	Part No.
No. of Safety Key Adaptors required	1 - 9



or

If you've selected an I6/I7 or A6/A7 then select a releasing lock.

If you've selected a Push IR adaptor then select a releasing lock.

pro i
If a Safety Key Adaptor is not required leave part number blank and go to Step 7

pro i
Total Extracted, Safety & Access Locks in one configuration is Max 9

Step 7: Choose an Access Key Adaptor


Adaptors



Part No. A K

Description	Part No.
Standard Lock	L
Releasing Lock (must be used if a Push IR or EI Handle and Head used).	R

Description	Information		Part No.
Standard Lock no dustcover	Ensures door cannot be opened without access key. Access key could be held by authorised individuals (e.g. maintenance) or it could have been released by a separate unit	CLIN	1
Standard Lock with dustcover	Same as AK_1 but with dustcover for dusty environments	CLIS	2
Standard Lock with padlockable dustcover	Same as AK_1 but padlockable dustcover allows lockout feature	CLIL	3
Masterable Lock no dustcover	Same as AK_1 but master lock allows a single key to override all locks (master key must be carefully controlled on site)	MLIN	6
Masterable Lock with dustcover	Same as AK_2 but master lock allows a single key to override all locks (master key must be carefully controlled on site)	MLIS	7
Masterable Lock with padlockable dustcover	Same as AK_3 but master lock allows a single key to override all locks (master key must be carefully controlled on site)	MLIL	8



or

If you've selected an I6/I7 or A6/A7 then select a releasing lock.

If you've selected a Push IR adaptor then select a releasing lock.

pro i

If an Access Key Adaptor is not required leave part number blank and go to Step 8

Description	Part No.
No. of Access Key Adaptors required	1 - 9


pro i

Total Extracted, Safety & Access Locks in one configuration is Max 9

Step 8: Choose an Electrical Switching / Locking Body



Electrical Switching / Locking



Part No.	Description	Information
SL	Short LOK Body	Solenoid controlled safety switch. Holds door locked until signal sent to unlock. No provision for control buttons
SR	Short LOK Body - Releasing (must be used if a Push IR or EI handle and head used).	Same as SL but allows Push IR or EI handle to override it
SE	Short LOK Body - Integrated Escape Release	Same as SL but it's integrated escape release button overrides locking mechanism and opens safety contacts (Does not work with key adaptors, EI or Push IR)

Part No.	Description	Information
LL	Long LOK Body	Solenoid controlled safety switch. Holds door locked until signal sent to unlock. With space for control buttons
LR	Long LOK Body - Releasing (must be used if a Push IR or EI handle and head used).	Same as LL but allows Push IR or EI handle to override it
LE	Long LOK Body - Integrated Escape Release	Same as LL but it's integrated escape release button overrides locking mechanism and opens safety contacts (Does not work with key adaptors, EI or Push IR)

Part No.	Description	Information
ZL	Slimline LOK Body	Solenoid controlled safety switch. Holds door locked until signal sent to unlock. No provision for control buttons. Only 40mm wide
ZR	Slimline LOK Body - Releasing (must be used if a Push IR or EI handle and head used).	Same as ZL but allows Push IR or EI handle to override it. Only 40mm wide

Part No.	Description	Information
ST	Stop Body	Safety switch

Part No.	Description	Information
EX	EU Explosion Stop Body	Safety switches suitable for explosive environments with EU certification
UX	US Explosion Stop Body	Safety switches suitable for explosive environments with US certification

Part No.	Description	Information
FT	To Terminate non-switch configurations	Terminates non-switch configurations (not suitable for units with Push IR or EI handle)

If you've selected an I6/I7 or A6/A7 then select a releasing lock.

If you've selected a Push IR adaptor then select a releasing lock.

pro i
For proNet configurations proLOK+ body is only needed if 5 - 8 pushbutton / lamp options are required

pro i
A Slimline proLOK works best with an S6 head to give a final product that is only 40mm wide

pro i
If an Electrical Switching / Locking Body is not required leave part number blank and continue to Step 10

Step 9: Choose Electrical Switching / Locking Body Options

IMPORTANT NOTE:


- For all *proLOK proNet* configurations go to step 10b.
- For all *proLOK+ proNet* configurations first go to step 10a then 10b.

Part No.

Voltage Options	Part No.
No Voltage (eg Foot)	0
110v	1
230v	2
24v	4
100v	5
48v	7
Asi	8
110v Solenoid / 24v Control (LOK only)	S
110v Control / 24v Solenoid (LOK only)	C
<i>proNet</i> Connection (Not available for Slimline <i>proLOK</i>)	P

pro i
Slimline *proLOK*
can only be
configured in
24v

Override Options	Part No.
Stop/EXP/UXP	0
PTU - Key Override	1
PTU - Knob Override	2
PTU - Screwdriver Override	3
PTL (24v, 110v & ASi only)	6
PTL with fully monitored solenoid (ZL / ZR only)	7



Other PCB Options	<i>proBody</i> Types	Part No.
Std & Sourcing	ALL	1
Std & Sinking	ST Only	2
Std & Sourcing (3 x NC)	ST Only	3
Std & Sourcing (Y&G LEDS)	SL, SR, LL & LR Only	4
Un-Monitored Sol & Sourcing	SL, SR, LL, ZL & LR, ZR Only	6
Un-Monitored Sol & Sourcing (Y&G LEDS)	SL, SR, LL & LR Only	7
Individual Safety Control for Sol & Actuator	SL, SR, LL, LR, SE & LE Only	8


pro i
Not available for
ZL or ZR

pro i
This is ordered
by 99% of our
customers

Step 10a: Choose options for Separate Option Pod or proLOK+ Body

Option Pods

Separate Option Pod with 4 hole positions



Separate Option Pod with 2 hole positions



proLOK+ Body with 2 hole positions



proLOK+ Body with 4 hole positions



pro i
If you order just one or two pushbuttons we will retain the order but position them top left and top right



Select Unit	Pod Type	Terminals OR QD	AS-i
Stand alone Pod with No holes on top of pod case (stand alone unit)	B	0	5
Pod with one hole on top of pod case for fitting to proStop Body	B	1	6
Pod with two holes on top of pod case for fitting to proLOK Body	B	2	7
proLOK+ Body switch information	L	0	5

Part No.	Pushbutton / Lamp Options - 24v only
0	Blank
1	Red Lamp
2	Yellow Lamp
3	Green Lamp
6	Blue Lamp
7	White Lamp
E	E-Stop (twist reset)
H	E-Stop (with additional monitoring contacts, twist reset)
P	E-Stop (pull reset)
U	E-Stop (illuminated twist reset)
L*	Latching selector switch (illuminated)
M*	Momentary selector switch (illuminated)
A*	Latching key switch (90 degree)
R	Red illuminated pushbutton non latching
Y	Yellow illuminated pushbutton non latching
G	Green illuminated pushbutton non latching
B	Blue illuminated pushbutton non latching
W	White illuminated pushbutton non latching
K	Black non illuminated pushbutton non latching

Part No.	Sensors - 24v only
N	No additional switch required
C	Coded Magnet - Left Hand (see step 2 for handling)
D	Coded Magnet - Right Hand (see step 2 for handling)
S	RFID - Left Hand (see step 2 for handling)
T	RFID - Right Hand (see step 2 for handling)

pro i
L, M & A Options can only be fitted in top right or bottom left positions

pro i
If an Option Pod or Long LOK Body is not required leave part number blank and continue to Step 11

Step 10b: Choose options for *proNet* Option Pod

Option Pods

pro i
If you order just one or two pushbuttons we will retain the order but position them top left and top right




Select Unit	PROFINET	Ethernet/IP
Stand alone <i>proNet</i> Pod	0	3
<i>proNet</i> Pod mounted below a <i>proLOK</i> or <i>proLOK+</i> unit or <i>proStop</i> unit	2	5

Part No.	Pushbutton / Lamp Options - 24v only
0	Blank
1	Red Lamp
2	Yellow Lamp
3	Green Lamp
6	Blue Lamp
7	White Lamp
E	E-Stop (twist reset)
H	E-Stop (with additional monitoring contacts, twist reset)
P	E-Stop (pull reset)
U	E-Stop (illuminated twist reset)
L*	Latching selector switch (illuminated)
M*	Momentary selector switch (illuminated)
A*	Latching key switch (90 degree)
R	Red illuminated pushbutton non-latching
Y	Yellow illuminated pushbutton non-latching
G	Green illuminated pushbutton non-latching
B	Blue illuminated pushbutton non-latching
W	White illuminated pushbutton non-latching
K	Black non illuminated pushbutton non-latching

Connection Options		
AIDA with 'B coded' external safety switch	0	4
AIDA with 'A coded' external safety switch	0	5
AIDA connectors	0	6
3 M12 QD set - 1 Power 2 Data	0	7
4 M12 QD set - 1 Power 1 External Safety Switch 2 Data	0	9
4 M12 QD set - 2 Power 2 Data	1	0
4 QD set - 2 Power (7/8s) 2 Data (M12)	1	1
AIDA connectors with 'A coded' external double safety switch	1	5

pro i
L, M & A Options can only be fitted in top right or bottom left positions

Pushbutton / Lamp positions for up to 4 selections



Pushbutton / Lamp positions for up to 2 selections



IMPORTANT NOTE:

- If you have selected a *proNet* option pod then your *amGardpro* configuration process has now finished. There are no further steps required.
- If you don't require a *proNet* option pod then proceed to Steps 10c, 11 or 12.


Step 10c: Choose options for Slimline Option Pod

Option Pods



Ordering Sequence
 1 - Top Position
 2 - Middle Position
 3 - Bottom Position

pro i
 Majority of customers prefer common power supply due to the reduced wiring complexity



pro i
 If an Option Pod or Long LOK Body is not required leave part number blank and continue to Step 11

Step 11: Do you want a Key Switch Option Pod?

Option Pods



pro i
Removal of the key operates a set of safety rated switches. Common uses are: request machine stop, enable teach mode and prevent inadvertent re-start


Part No.

B	K		
---	---	--	--

Select Unit	Part No.
Stand alone Pod with No holes on top of pod case (stand alone unit)	0
Pod with one hole on top of pod case for fitting to <i>proStop</i> Body	1
Pod with two holes on top of pod case for fitting to <i>proLOK</i> Body	2



Description		Part No.
Standard Lock no dustcover	CLIN	1
Standard Lock with dustcover	CLIS	2
Standard Lock with padlockable dustcover	CLIL	3
Masterable Lock no dustcover	MLIN	6
Masterable Lock with dustcover	MLIS	7
Masterable Lock with padlockable dustcover	MLIL	8



pro i
If a Key Switch Option Pod is not required leave part number blank and continue to Step 12

Step 12a: Quick Disconnect Connector Options




Quick Disconnect Connector Options

D1		D2		D3		D7		D8		D9		E3		E4		F2	
No. Pins	5	No. Pins	12	No. Pins	8	No. Pins	10	No. Pins	12	No. Pins	12	No. Pins	10	No. Pins	19	No. Pins	19
Max Voltage	300v	Max Voltage	300v	Max Voltage	60v	Max Voltage	60v	Max Voltage	60v	Max Voltage	300v	Max Voltage	300v	Max Voltage	300v	Max Voltage	300v
Connector	M12	Connector	UN2	Connector	M12	Connector	M12	Connector	M12	Connector	M23	Connector	UN2	Connector	UN2	Connector	M23
1	Brown	1	Orange	1	White	1	White	1	White	1	Brown	1	Orange	1	Violet	1	Violet
2	White	2	Blue	2	Brown	2	Brown	2	Brown	2	Brown/White	2	Blue	2	Red	2	Red
3	Blue	3	White/Black	3	Green	3	Green	3	Green	3	Blue	3	White/Black	3	Grey	3	Grey
4	Black	4	Red/Black	4	Yellow	4	Yellow	4	Yellow	4	White	4	Red/Black	4	Red/Blue	4	Red/Blue
5	Grey	5	Green/Black	5	Grey	5	Grey	5	Grey	5	Green	5	Green/Black	5	Blue	5	Green
		6	Orange/Black	6	Pink	6	Pink	6	Pink	6	Yellow	6	Orange/Black	6	Green	6	Blue
		7	Blue/Black	7	Blue	7	Blue	7	Blue	7	Grey	7	Red	7	Brown	7	Grey/Pink
		8	Black/White	8	Red	8	Red	8	Red	8	Pink	8	Green/Yellow	8	White/Green	8	White/Green
		9	Green/Yellow					9	Orange	9	Red	9	Black	9	White/Yellow	9	White/Yellow
		10	Red					10	Tan	10	Black	10	White	10	White/Grey	10	White/Grey
		11	White					11	Black	11	Violet			11	Black	11	Black
		12	Black					12	Violet	12	Green/Yellow			12	Green/Yellow	12	Green/Yellow
														13	Yellow/Brown	13	Yellow/Brown
														14	Brown/Green	14	Brown/Green
														15	White	15	White
														16	Yellow	16	Yellow
														17	Pink	17	Pink
														18	Grey/Brown	18	Grey/Brown
														19	Grey/Pink	19	Brown

Step 12b: Quick Disconnect Connector Options

Part No.	T Wiring					Left Hand QD		Right Hand QD	
	T	#	#	#	#	#			

Contact Fortress engineering to be assigned T Wiring number



		No. Pins	Connector
0	0		
D	1	5	M12
D	2	12	UN2
D	3	8	M12
D	7	10	M12
D	8	12	M12
D	9	12	M23
E	3	10	UN2
E	4	19	UN2
F	2	19	M23



Image showing no connectors - 0 0



pro
i

proStop, Slimline proLok and Slimline proOption Pods can only be configured with 1 connector