

User manual
Benutzerhandbuch

Easyview Touch-Panel <-> Pluto-SPS
Easyview Touch-Panel <-> Pluto-SPS

PRELIMINARY

Index

| | |
|---|---|
| Cable diagram | 3 |
| Pluto safety PLC <-> Easyview MT8070iH: | 3 |


Cable diagram

Pluto safety PLC <-> Easyview MT8070iH:

Remark:

Pluto needs +5V on Pin 4 = RTS-signal from RS232 / PC (COM1)

Easyview doesn't support +5V!



| Pluto connector | Cable colour | HMI connector | Function |
|-----------------|--------------|---------------|--------------------------|
| 1 | Red | 5 | Signal ground |
| 2 | Blue | 2 | Data signal Pluto to HMI |
| 3 | Green | 3 | Data signal HMI to Pluto |
| 4 | Yellow | USB-A Pin 1 | 5 Volt (from USB) |

Be carefully! Short circuit on USB will destroy the USB port!